



Important reminder:

If you are using the T80 Racing Wheel or T80 Ferrari 488 GTB Edition on PC (Windows® 10, 11), **it is imperative that you first install the corresponding PC driver** (should you fail to do so, some axes and/or buttons will not work properly).

To install the driver:

- Go to <http://support.thrustmaster.com/>.
- Click Racing Wheels / T80 Racing Wheel, then click Drivers.
- Download and install the Drivers package

NB: On PC with the T80 Racing Wheel (non-Ferrari version), the USB sliding switch on the wheel base must always be set to the PS4 position before plugging the USB.

More details about the PC driver of the T80 Ferrari 488 GTB Edition here:


https://ts.thrustmaster.com/download/accessories/Manuals/T80RW/T80Ferrari_PC_Setup.pdf

More details about the PC driver of the T80 Racing Wheel (non-Ferrari version) here:

https://ts.thrustmaster.com/download/accessories/Manuals/T80RW/T80_PC_Setup.pdf

In the Options of the game

Access at **OPTIONS / SETTINGS / CONTROLS / CHANGE INPUT MAPPING / WHEEL / CUSTOM WHEEL PROFILE** and program manually all functionalities on the T80 Wheel: Axes (Accelerate, Brake, Steering) and all buttons (E-brake, Shift Down, Shift Up, etc....)




SUGGESTED GAMEPLAY CONTROL ON THE T80 WHEEL:

Buttons on the T80 wheel	Functionality in the game
CROSS	TELEMETRY
ROUND	E-BRAKE
TRIANGLE	SWITCH CAMERA
SQUARE	REWIND
L1	SHIFT DOWN
R1	SHIFT UP
L2	PING/CHASEBREAKER
R2	MAP
L3	TOGGLE CONVERTIBLE
R3	ACTIVATE
SHARE-CREATE	PHOTO MODE
PS	ACTIVATE ANA
OPTIONS	PAUSE
D-Pad Up	HORN
D-Pad Left	LOOK LEFT
D-Pad Up	LOOK RIGHT
D-Pad Down	LOOK BACK

STEERING IMPROVEMENT:

To improve the T80 steering in this game, access at **OPTIONS / SETTINGS / ADVANCED CONTROLS** and reduce the **STEERING LINEARITY** slider.



Remark:

In this game, with the T80 wheel, it's not possible to navigate in the menu of the game with the wheel (you must use the Keyboard or the mouse).